





**Roomba**  
Knowledge

## Roomba Anatomy




## Roomba Set-up


- 1 Place battery into Roomba Robotic Floorvac.  
(press down on both ends)



- 2 Charge for 3 hours — while you're waiting, load batteries into your Virtual Wall and Remote.




- 3 Clean the floor of loose stuff like you would before using a traditional vacuum. If you don't vacuum over it, don't use Roomba over it (e.g., rug tassels, power and blind cords).



## Roomba Set-up

- 4 Set up your Virtual Wall to keep Roomba where you want it and away from where you don't.




### 5 Battery indicator



Color of Battery Indicator	Battery Status
Pulsing Amber	Charging
Green	Fully Charged
Amber	Partially Charged
Red	Almost Fully Discharged
Flashing Red	Fully Discharged

## Roomba Set-up – Self-Charging Home Base


- 6 Set up the Home Base against a wall in a location with a clear approach and no obstructions in front.



- 7 When Roomba completes a mission or the battery is running low, it will find its way back to the Home Base and re-charge for the next mission. There will be times Roomba can't find its Home Base. If this happens, place Roomba on the Home Base or plug into the wall.

*To manually send me back to recharge, I need to be placed within 4-5 feet in front of the Home Base. Then press both the "Clean" and "Spot" button at the same time.*


- 8 To restart Roomba when it is on the Home Base, just press "Clean" and watch Roomba GO!



## Roomba at Work

- 1 Place Roomba in the center of the room and press "Clean."  
Roomba will automatically calculate how long it needs to clean your entire room.

or



- 2 Use "Spot" to intensively clean a 3 ft. diameter area.


*Spot works great on spills or in high traffic areas.*

- 3 Use "Max" for extended cleaning time. Roomba will clean for up to 120 minutes before shutting off.

- 4 "Dirt Alert" will illuminate when Roomba has detected dirt that requires special attention. When the dirt is gone, Roomba will continue in its standard cleaning mode.

*In dirtier areas, I increase my cleaning intensity.*

- 5 To pause Roomba, hit any button on the panel. To stop, pick it up.




## Roomba at Work


- 6 When Roomba stops, check the indicator light.

*If my mission is abandoned, pick me up and examine my brushes. Remove any obstructions before restarting.*

### Roomba stops for 3 reasons




- 7 When Roomba is not cleaning it is recommended that you keep it plugged in. That will help the battery stay in peak condition.
- 8 Use your remote to power up, start a cleaning cycle, or direct Roomba to the dirt.




## Keep Roomba Running

- ❶ Empty the bin over a trash barrel after each use. Don't forget to remove the filter assembly and empty the 2nd chamber.




- ❷ Remove and clean the brushes every 10 uses.



- ❸ Inspect and wipe the sensors clean.  
(when you clean brushes)



Cotton swabs  
work great!



- ❹ Inspect the vacuum inlet  
and clean debris as  
needed.

- ❺ Change filters.

I recommend  
you do this every 2  
months.





## Roomba Last Thoughts

The Roomba Robotic Floorvac is easy to use,  
but under the hood it's a complex robot. We're  
Roboticians, the retailer is not. If you have  
questions or comments, we're anxious to help.


Please visit us at  
[www.irobot.com](http://www.irobot.com)  
or  
call 877-855-8593

iRobot, Roomba, Virtual Wall and "If it's down there, we'll get it" are trademarks of iRobot Corporation.

© 2004 iRobot Corporation. All Rights Reserved

US Pat Nos 6,594,844 and 6,690,134. Additional Patents Pending  
Burlington, MA 01803

Version: 4110-V1





**Roomba**

...smart  
...simple  
...clean

Model 4110